


⚠ 细化器/Atomizer



型号 Model	产品名称 Product name	进气压强 Inlet Pressure	进气接口(可选) Inlet nut screw	出气接口 Outlet nut screw	材质 Material
CO2-U	CO2 U型管 CO2 Diffuser U tube	—	6*4mm PU气管 6*4mm PU trachea	6*4mm PU气管 6*4mm PU trachea	304 stainless steel
CO2-DT	CO2细化片 CO2 Diffuser Tablet	> 0.15 Mpa	M5*0.8	M5*0.8	6061 aluminum alloy
CO2-N-D60	CO2止逆细化器60mm CO2 Diffuser non-return 60mm	> 0.15 Mpa	6*4mm PU气管 6*4mm PU trachea	M5*0.8	304 stainless steel
CO2-N-D250	CO2止逆细化器250mm CO2 Diffuser non-return 250mm	> 0.15 Mpa	6*4mm PU气管 6*4mm PU trachea	M5*0.8	304 stainless steel
CO2-N-D300	CO2止逆细化器300mm CO2 Diffuser non-return 300mm	> 0.15 Mpa	6*4mm PU气管 6*4mm PU trachea	M5*0.8	304 stainless steel
CO2-N-D400	CO2止逆细化器400mm CO2 Diffuser non-return 400mm	> 0.15 Mpa	6*4mm PU气管 6*4mm PU trachea	M5*0.8	304 stainless steel

⚠ 止逆阀与二氧化碳检测器/check valve and CO2 External atomizer

型号 Model	产品名称 Product name
CV-S	单头止逆阀 Single head check valve
CV-D	双头止逆阀 Double head check valve
CO2-MS	二氧化碳检测器套装 CO2 Monitor set
CO2-MF	二氧化碳检测液 CO2 Monitoring fluid



⚠ 保修声明/Warranty Terms

一、对所售产品提供1年期免费质保,即1年内,如产品存在质量问题,可免费更换维修。非质量问题及过保,所进行的维修更换将收取合理费用。

二、以下非本公司因素造成的产品问题均不在免费维修范围:

- 未按说明书操作使用、电压不匹配、缺少必要的保养等;
- 错误使用以及自行不当修理导致的故障或损坏;
- 其他外来因素造成的故障或损坏;

由于国家或地区不同,部分权利可能只适用于特定客户。

I. The products sold are guaranteed for one year free of charge, that is, within one year, if there is any quality problem of the products, they can be replaced or repaired for free. A reasonable fee will be charged for maintenance and replacement of non-quality issues and after warranty overruns.

II. The following product problems not caused by the company are not covered by free maintenance:

- Not operating according to the manual, voltage mismatch, lack of necessary maintenance, etc.;
- Malfunctions or damages caused by wrong use or improper repair by oneself.
- Failure or damage caused by other external factors.


4. Failure not caused by our products; Depending on the country or region, some rights may only apply to specific customers.



WEEK AQUA

二氧化碳系列使用说明书

Aquarium CO₂ series User Manual



珠海威尔康光电有限公司

Zhuhai WEEK Photoelectric Co., Ltd.

① 广东省珠海市香洲区金鼎工业园金峰西路29号B栋3楼/1楼


② 3/F, Building B, No. 29 Jinfeng West Road, Jinding

Industrial Park, Xiangzhou District, Zhuhai City

☎ +86 0756-3386506 ☎ Sales@weekaqua.com


🌐 www.weekaqua.com

⚠️ 二氧化碳减压阀/Aquarium CO2 regulators



型号 Model	产品名称 Product name	进气压强 Inlet Pressure	出气压强 Outlet Pressure	进气接口(可选) Inlet nut screw	出气接口 Outlet nut screw
C02-MV-S	单表减压阀 Single Meter Valve	0.5Mpa-15Mpa	0.3Mpa -0.6Mpa	G5/8 ,W21.8 ,M22	M10*1.0
C02-MV-D	双表减压阀 Double Meter Valve	0.5Mpa-15Mpa	0.3Mpa -0.6Mpa	G5/8 ,W21.8 ,M22	M10*1.0
C02-MV-S-S	单表减压阀-电磁款 Single meter solenoid valve	0.5Mpa-15Mpa	0.3Mpa -0.6Mpa	G5/8 ,W21.8 ,M22	M10*1.0
C02-MV-D-S	双表减压阀-电磁款 Double meter solenoid valve	0.5Mpa-15Mpa	0.3Mpa -0.6Mpa	G5/8 ,W21.8 ,M22	M10*1.0

⚠️ 安装方法/Installation



- 1.将双表减压阀扭到钢瓶上手扭紧即可
- 2.打开单头计泡器上盖加入3/4的水
- 3.电磁阀接上电源线，然后安装到微调阀上
- 4.电磁阀与电源适配器连接
- 5.电源适配器通电
- 6.打开气瓶阀门（打开气瓶阀门前必须确认单头电磁阀已经通电）
- 7.计泡器接上气管
- 8.气管另一头接上自己的雾化设备即可
- 9.打开单头微调阀调节气量

⚠️ C02-MV-S / C02-MV-D 忽略步骤3,4,5

⚠️ C02-MV-S / C02-MV-D Ignore steps 3,4,5.


- 1.Twist the Double meter solenoid valve onto the cylinder and tighten it by hand
- 2.Open the top lid of the single-head bubbler and add 3/4 of the water
- 3.Solenoid valve connected to the power cord, Then install to the single head trim valve
- 4.Solenoid valve connected to power adapter
- 5.Power adapter energized
- 6.Open the cylinder valve (Make sure the single solenoid valve is energized before opening the cylinder valve)
- 7.The bubbler is connected to the air hose
- 8.Just connect the other end of the air hose to your own nebulizing equipment
- 9.Open the trimmer valve to adjust the air volume

⚠️ 二氧化碳多通路器/ CO2 Multi-pass splitter




型号 Model	产品名称 Product name	进气压强 Inlet Pressure	进气接口(可选) Inlet nut screw	出气接口 Outlet nut screw
CO2-1-2	CO2双通 CO2 Way Splitter-Two	0.3Mpa -0.6Mpa	M10*1.0	M10*1.0
CO2-1-3	CO2三通 1 Turn 3 Air Outlet	0.3Mpa -0.6Mpa	M10*1.0	M10*1.0
CO2-1-6	CO2六通 1 Turn 6 Air Outlet	0.3Mpa -0.6Mpa	M10*1.0	M10*1.0

⚠️ 二氧化碳计泡器与微调阀/ CO2 Bubble Counter And Fine-Tuning Valve



型号 Model	产品名称 Product name	进气压强 Inlet Pressure	进气接口(可选) Inlet nut screw	出气接口 Outlet nut screw
CO2-TV-S	单头微调阀 Single-head fine-tuning valve	1 Mpa	G1/8	M10*1.0
CO2-W-IN	记泡器注水接头 Water injection	1 Mpa	M18*1.0	M18*1.0
CO2-BC-S	单头计泡器 Single head bubble counter	1 Mpa	M10*1.0	M10*1.0
CO2-BC-D	双头计泡器 Double-head bubble counter	1 Mpa	M10*1.0	M10*1.0
CO2-BC-S-W	单头计泡器-注水款 Single head bubble counter -Water injection	1 Mpa	M10*1.0	M10*1.0
CO2-BC-D-W	双头计泡器-注水款 Double-head bubble counter-Water injection	1 Mpa	M10*1.0	M10*1.0

⚠️ 二氧化碳电磁阀/ CO2 Solenoid valve



型号 Model	产品名称 Product name	进气压强 Inlet Pressure	进气接口(可选) Inlet nut screw	出气接口 Outlet nut screw
CO2-SV-S-BC	记泡器电磁阀 bubble counter solenoid valve	0.3Mpa -0.6Mpa	M10*1.0	M10*1.0
CO2-SV-S	单头电磁阀 Single head solenoid valve	0.3Mpa -0.6Mpa	M10*1.0	M10*1.0
CO2-SV-D	双头电磁阀 Double head solenoid valve	0.3Mpa -0.6Mpa	M10*1.0	M10*1.0